

## **CARE INSTRUCTION INFORMATION FOR WICKER BASKETS**

Wicker is a natural product which needs protection to maintain its finish and ensure a long and useful life. We recommend the following actions to keep your basket looking good:

- If possible, do not leave your basket outside for a prolonged length of time.
- Try to store your basket in an area protected from weather elements.
- If your basket gets wet, dry thoroughly as soon as possible after use.
- Applying two coats of yacht varnish or other waterproofing treatment before use will help prolong the life of the basket.
- Apply the treatment occasionally to give continued protection.

## **CAUTION**

- Not suitable for all types of bikes.
- To avoid causing damage or wear to the bike frame or handlebar, ensure that the basket is secure at all times.

## **WARNING**

- Do not load more than 5kg into handlebar basket, as this can affect steering.
- Ensure all brake and gear cables function correctly after fitting.
- Check the basket does not affect the steering of the bicycle before riding, at all times.